

### Mikrofonbelegungen von CB-Funkgeräten

Hier eine kleine Auflistung von Mikrofonbuchsen verschiedener Hersteller von Funkgeräten

Hersteller	Modell	1	2	3	4	5	6	7	8
ALAN	ALAN 95 Plus	2,5MTM/3,5MSP							
ALAN	ALAN 98 D	2,5MTM/3,5MSP							
ALAN	ALAN 100 D								
ALAN	AIAN100 E								
ALAN	MIDLAND ALAN 18	MIC	RX	TX	UP- DOWN	GND	DC		
ALAN	MIDLAND ALAN 21E	MIC	RX	TX	UP- DOWN	GND	DC		
ALAN	MIDLAND ALAN 27E	MIC	RX	TX	UP- DOWN	GND	DC		
ALAN	MIDLAND ALAN 28D	MIC	RX	TX	UP- DOWN	GND	DC		
ALAN	MIDLAND ALAN 48D	MIC	RX	TX	UP- DOWN	GND	DC		
ALAN	MIDLAND ALAN 48Plus	MIC	RX	TX	UP- DOWN	GND	DC		
ALAN	MIDLAND ALAN 54	MIC	GND	RX	TX				
ALAN	MIDLAND ALAN 58E	MIC	RX	TX	UP- DOWN	GND	DC		
ALAN	MIDLAND ALAN 77Plus	MIC	RX	TX	UP- DOWN	GND	DC		
ALAN	MIDLAND ALAN 78Plus	MIC	RX	TX	UP- DOWN	GND	DC		
ALBRECHT	AE 2200	2,5/3,5mm							
ALBRECHT	AE 4002	MIC	RX	TX	UP- DOWN	GND	DC		
ALBRECHT	AE 4100	MIC	RX	TX	UP- DOWN	GND	DC		
ALBRECHT	AE 4180	MIC	RX	TX	UP- DOWN	GND	DC		
ALBRECHT	AE 4200	MIC	GND	RX	TX				
ALBRECHT	AE 4300	MIC	GND	RX	TX				
ALBRECHT	AE 4400	MIC	GND	RX	TX				
ALBRECHT	AE 4500	MIC	RX	TX	UP- DOWN	GND	DC		
ALBRECHT	AE 4550	MIC	RX	TX	UP- DOWN	GND	DC		
ALBRECHT	AE 4600	MIC	RX	TX	UP- DOWN	GND	DC		
ALBRECHT	AE 4650	MIC	RX	TX	UP- DOWN	GND	DC		
ALBRECHT	AE 4700	MIC	RX	TX	UP-	GND	DC		

					DOWN				
ALBRECHT	AE 4800	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	AE 4800 FM	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	AE 5000	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	AE 5080	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	AE 51 00	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	AE 51 50	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	AE 5180	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	AE 5280	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	AE 8000	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	ALBRECHT 40I2	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	ALPHA 40 B FM	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	ALPHA 40 FM	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	ALPHA 4000 B FM	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	ALPHA 4000 FM	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	P 1000	GND	MIC	TX	RX				
ALBRECHT	PHANTOM 4012	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	PHANTOM 4012 B	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	SKYLINE SM 2010	MIC	RX	TX	UP-DOWN	GND	DC		
ALBRECHT	SKYLINE4000	MIC	RX	TX	UP-DOWN	GND	DC		
ASTRACOM	MA4012	MIC	GND	RX	TX				
ASTRACOM	MA40FM	MIC	GND	RX	TX				
DANITA	1540	GND		TX	MIC				
DANITA	608	2,5MTM/3,5MSP							
DANITA	Mark 3	MIC	GND	TX	DC	RX			
DANITA	Mark 5	MIC	GND	TX	DC	RX			
DNT	B 2740 AM/FM DNT	MIC	GND	TX	GND	TX			
DNT	B 40 AM/FM DNT	MIC	GND	TX	GND	TX			

DNT	CARAT (EXCLUSIV)	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	Cockpit (II)	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	CONTACT 40 FM	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	Contact II/traffic I	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	Contact III	MIC	S-M	TX	GND	MUTE	6V	UP-DWN	
DNT	Coupé	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	CV 2000	GND	NC	TX	MIC	NC			
DNT	Formel I	GND	NC	TX	MIC	NC			
DNT	Highway	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	KURIER 5040	MIC	RX	TX	UP-DOWN	GND	DC		
DNT	KX 4012 Colonia	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	M 2740 AM/FM	MIC	GND	TX	GND	TX	9V		
DNT	M 40 AM/FM	MIC	GND	TX	GND	TX	9V		
DNT	Meteor 8012 DNT	MIC	SCAN	TX	DC 12V	UP-DOWN	GND		
DNT	Meteor Selektiv DNT	MIC	SCAN	TX	DC 12V	UP-DOWN	GND		
DNT	Rallye	GND	NC	TX	MIC	NC			
DNT	Saphir	MIC	SCAN	TX	DC 12V	UP-DOWN	GND		
DNT	Saphir 8012	MIC	SCAN	TX	DC 12V	UP-DOWN	GND		
DNT	Scanner	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	Scanner- fm	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	strato I	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	strato plus	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	Transit	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	Truck- Star	MIC	RX	TX	GND	MUTE	6V	UP-DWN	
DNT	Zirkon	MIC	SCAN	TX	DC 12V	UP-DOWN	GND		
DNT	Zirkon I	MIC	SCAN	TX	DC 12V	UP-DOWN	GND		
KAISER	KA 9018 FM/40	GND	TX	MIC	TX	GND			
KAISER	KA 9040 FM	GND	MIC	TX	RX				
KAISER	KE 90 1 5/40	GND	MIC	TX	RX				

	Basis								
KAISER (NFT)	CBX 40	2.5/3,5mm							
KAISER (NFT)	KA 4000 FM	GND	TX	MIC	TX	GND			
KAISER (NFT)	KA 901 2	MIC	GND	RX	TX				
KAISER (NFT)	KA 901 4	MIC	GND	RX	TX				
KAISER (NFT)	KA9050	GND	MIC	TX	RX				
MAXON	MX 1000	MIC	RX	TX	UP-DOWN	GND	DC		
MAXON	MX 2000	MIC	RX	TX	UP-DOWN	GND	DC		
MAXON	MX 3000	MIC	RX	TX	UP-DOWN	GND	DC		
MAXON	MX40-12 Mercury	GND	MIC	TX	RX				
PAN	MEGA- TOP AM/FM	MIC	GND	RX	TX				
PAN	MEGA- TOP FM	MIC	GND	RX	TX				
PAN	MINI- TOP AM/FM	MIC	GND	RX	TX				
PAN	MINI- TOP FM	MIC	GND	RX	TX				
PAN	MINI- TOP LCD 8012	MIC	RX	TX	UP-DOWN	GND	DC		
PAN	MIRAGE	MIC	RX	TX	UP-DOWN	GND			
PAN	P 2000 Basis	MIC	GND	RX	TX				
PAN	PC 40	GND	MIC	TX	RX				
PAN	PC 40	MIC	GND	RX	TX				
PAN	PC 4012	MIC	RX	TX	UP-DOWN	GND	DC		
PAN	PC 50	MIC	GND	RX	TX				
PAN	PC 505	MIC	GND	RX	TX				
PAN	PC 80	MIC	RX	TX	UP-DOWN	GND	DC		
PAN	PCM 8112	MIC	RX	TX	UP-DOWN	GND	DC		
PAN	SCAN 4000 Basis	MIC	GND	RX	TX				
PRESIDENT	George	MIC	RX	TX	UP-DOWN	GND	DC		
PRESIDENT	Harry AM/FM	MIC	TX	GND	NC	RX			
PRESIDENT	Herbert AM/FM	GND	MIC	TX	RX				

PRESIDENT	Jackson CEPT	MIC	RX	TX	UP-DOWN	GND	DC		
PRESIDENT	James	MIC	RX	TX	UP-DOWN	GND	DC		
PRESIDENT	JFK AM/FM	MIC	RX	TX	UP-DOWN	GND	DC		
PRESIDENT	Johnson CEPT	MIC	RX	TX	UP-DOWN	GND	DC		
PRESIDENT	PC 40	GND	MIC	TX	RX				
PRESIDENT	Taylor AM/FM	MIC	RX	TX	UP-DOWN	GND	DC		
PRESIDENT	Valery AM/FM	MIC	RX	TX	UP-DOWN	GND	DC		
PRESIDENT	Wilson AM/FM	MIC	RX	TX	UP-DOWN	GND	DC		
STABO	Magnum m	MIC	GND	RX	TX				
STABO	XF 2540 Basis	MIC	GND	RX	TX				
STABO	XF 401 2n Basis	MIC	GND	RX	TX				
STABO	XF 4012 Basis	MIC	GND	RX	TX				
STABO	XF 5012 Basis	MIC	GND	RX	TX				
STABO	XF4000 Basis	MIC	GND	RX	TX				
STABO	XM 2240	MIC	GND	RX	TX				
STABO	XM 3200	MIC	GND	RX	TX				
STABO	XM 3400	MIC	GND	RX	TX				
STABO	XM 3500	MIC	GND	RX	TX				
STABO	XM 4000	MIC	GND	RX	TX				
STABO	XM 401 2	MIC	GND	RX	TX				
STABO	XM 4012n	MIC	GND	RX	TX				
STABO	XM 4042	MIC	GND	RX	TX				
STABO	XM 5000	MIC	GND	RX	TX				
STABO	XM 5012	MIC	GND	RX	TX				
STABO	XM 601 2	MUTE	UP-DOWN	DC	GND	MIC	TX	AUDIO	EMG
STABO	XM 7042/7082	MIC	RX	TX	F-T	GND			
STABO	xrc twinstar	MUTE	UP-DOWN	DC	GND	MIC	TX	AUDIO	EMG
TEAM	NEU und 80 CH	MIC	RX	TX	UP-DOWN	GND	DC		
TEAM	Classic 4012	MIC	GND	RX	TX				
TEAM	Compact 4012	MIC	GND	RX	TX				
TEAM	EURO 3004 F Basis	MIC	GND	RX	TX				
TEAM	EURO 3100 Basis	MIC	GND	RX	TX				
TEAM	EURO 3102 Basis	MIC	GND	RX	TX				



ZODIAC	B 4040 Basis	MIC	GND	TX	DC	RX			
ZODIAC	M 144	MIC	GND	TX	DC	RX			
ZODIAC	M 244	MIC	GND	TX	DC	RX			
ZODIAC	M 4040	MIC	GND	TX	DC	RX			
ZODIAC	M 8000	MIC	GND	TX	DC	RX			
ZODIAC	P2040(C)	MIC	GND	TX	DC	RX			

**Alle Angaben sind ohne Gewähr! Es wird nicht für Folgeschäden  
gehaftet!**

**MIC = Modulation, GND = Masse, RX = Audiosignal, TX = Senden,  
MUTE = Squelchsperre, EMG = Notrufkanal, UP-DOWN = Kanalwahl,  
DC = Versorgungsspannung, F-T = Funktionstasten**

**Irrtümer und Änderungen vorbehalten  
Aktiv CB Funk**